
7- Description of the table components


- Lifting table :



9176.05


- Wheel supports :





X110.0600


- Mini access ramps :






X110.0605


- Removable supports :





X110.0601


- Clamps :





X110.0400


- Pulling unit :





APS08.0800

- Runway decking plates :





X110.0603



CAUTION :
These runway decking plates cannot be used to lift the vehicle. Always place the vehicle to be lifted on the access plates or on the removable supports.